


# INSIDE MOUNT No Valance

## SHADE WIDTH

is measured from the end of  
the bracket cover to the end of  
the bracket cover when fully  
installed



## EXAMPLE

Ordered 48" Wide Inside Mount

Shade width fully installed


47 7/8 "



# OUTSIDE MOUNT No Valance

## SHADE WIDTH

is measured from the end of  
the bracket cover to the end of  
the bracket cover when fully  
installed



## EXAMPLE

Ordered 48" Wide Outside Mount


Shade width fully installed  
48"



# INSIDE MOUNT Semi Open


## SHADE WIDTH

is measured from the outside  
of the cassette's endcap to  
the end of other endcap



## EXAMPLE


Ordered 48" Wide Inside Mount



# OUTSIDE MOUNT Semi Open

## SHADE WIDTH


is measured from the outside  
of the cassette's endcap to  
the end of other endcap



**FABRIC WIDTH =  $1 \frac{3}{8}$ "**  
less than ordered width

## EXAMPLE

Ordered 48" Wide Outside Mount




**FABRIC WIDTH =  $46 \frac{5}{8}$ "**

# INSIDE MOUNT Fascia


## SHADE WIDTH

is measured from the outside  
of the fascia endcap to the  
end of other endcap



## EXAMPLE


Ordered 48" Wide Inside Mount



# OUTSIDE MOUNT Fascia

## SHADE WIDTH

is measured from the outside  
of the fascia endcap to the  
end of other endcap



## EXAMPLE

Ordered 48" Wide Outside Mount

